HEXNOVAS

HEAT EXCHANGER SPECIALISTS

Download & install

INSTALL > REQUEST LICENCE > IMPORT > START

1 Download the software

Use the download password supplied by HEXNOVAS.



2 Extract, then install

Extract the RAR archive. Run the installer from the extracted folder.

Full installer filename:
HEXNOVAS_Heat_Exchanger_Calculator_Setup_1.0.2.exe

Follow the installer instructions, then open the calculator.

The download password does not activate the calculator.

Illustrated guide - simplified diagrams; interface appearance may vary.

Request your licence

3 Copy your Machine ID

Use the ID displayed on the computer where you will run the software.



4 Email HEXNOVAS

Click Request New License, add your company and contact name, then send.



No email app? Paste the copied ID into your webmail and send it.

Import & start

5 Import the .hxl licence file

Save the file received from HEXNOVAS. Click Import License and select it.



6 Check green status, then start

When the status reads Licensed, click Start Calculator.



Wrong computer or expired licence? Email sales@hexnovas.com.